sign up log in tour help

Ask Ubuntu is a question and answer site for Ubuntu users and developers. It's 100% free.

Here's how it works:

Sign up

Anybody can ask a question Anybody can answer

The best answers are voted up and rise to the top

Share wireless Internet connection through ethernet

I want to share the wireless Internet connection on my desktop with my old laptop, through ethernet.

I have ticked the option "Make available to others" on both connections, on my desktop, but my laptop doesn't connect. Am I doing something wrong or is it a bug?







Before checking software configurations... how are you connecting the two PCs? If directly, you need a crossed cable (do they exist anymore?). See en.wikipedia.org/wiki/Ethernet_crossover_cable. Otherwise you'll need at least a bridge... – Rmano Oct 16 '13 at 15:52

I have done the exact same thing on 12.04 before. I am thinking there is a problem with network manager since i have Gnome 3.10 and it got updated today. — Christos Baziotis Oct 16 '13 at 18:03

3 @Rmano: According to that article, modern Ethernet hardware auto-negotiates so crossover cables are not needed. I've also done this before with ordinary Ethernet cables. – Mechanical snail Oct 30 '13 at 1:25

@Mechanical snail: thanks, I didn't noticed that. So I suppose I can dispose my precious manually connected cross-over cable :-) – Rmano Oct 30 '13 at 15:37

possible duplicate of Share Wireless connection with Wired Ethernet Port – bcbc Nov 29 '14 at 21:51

1 Answer

In the server computer:

1. On the computer connected to the Internet, click the network icon in the panel and go to "Edit Connections..." at the bottom of the menu.



2. Double click your **Wired Connection** (Leave your wireless connection untouched, the one connected to Internet and the one you want to share, as I understand)



3. In the "IPv4 Settings tab", select Method: "Shared to other computers"



- **4.** Reconnect clicking on the *Wired Network* so it gets its new IP address. (The two computers must be connected by an ethernet cable for this step, so connect them now if you have not already.)
- **5.** Click on "Connection Information" in the network menu and write down the IP address and network mask (in my case it was assigned 10.42.0.1/255.255.255.0 but I do not know if that will always be the case)




In the client computer:

6. Go to "Edit Connections..." and assign a "Manual" Method. Assign an IP assress in the same subnetwork (10.42.0.69 for example) and put the IP and network mask you wrote down in "Netmask" "Gateway" and "DNS servers"



- 7. Reconnect to the network to let the new settings be assigned.
- 8. Pat yourself in the back and surf away!!!



protected by Community • Jun 6 '15 at 4:06

Thank you for your interest in this question. Because it has attracted low-quality or spam answers that had to be removed, posting an answer now requires 10 reputation on this site.

Would you like to answer one of these unanswered questions instead?